

INSTALLATION INSTRUCTIONS

FLEX RECYCLED RUBBER FLOORING



An Intelli-Force Technology Company

SUGGESTED TOOL LIST:

Broom or vacuum
Chalk line & chalk
Gloves
Kraft paper (optional)
Metal straight edge or Drywall T-square
Standard tape measure
Utility knife and replacement blades
1/16" x 1/16" x 1/16" Square-notched trowel (glue down only)
100 lb roller (glue down only)
Blue painters tape
Denatured alcohol
Microfiber rags/towels

I. JOB SITE CONDITIONS

- A Installation should not begin until after all other trades are finished in the area. If the job requires other trades to work in the area after the installation of the floor, the floor should be protected with an appropriate cover. Kraft paper or plastic work well.
- B Areas to receive flooring should be weather tight and maintained at a minimum uniform temperature of 65°F (18°C) for 48 hours before, during, and after the installation.

II. SUBFLOORS

Recycled Rubber Flooring may be installed over concrete, approved Portland-based patching and leveling materials such as KOSTER American LevelStrong SLU or equivalent, and wood.

Note

KOSTER AMERICAN CORPORATION
585 Aviator Drive
Virginia Beach, VA 23453 Phone
(757) 425-1206 | Fax (757) 425-9951
info@kosterusa.com | www.kosterusa.com

Note

Gypsum-based patching and leveling compounds are not acceptable.

- A Wood Subfloors – wood subfloors should be double construction with a minimum thickness of one inch. The floor must be rigid, and free from movement with a minimum of 18 inches of well-ventilated air space below.

- B Underlayments – The preferred underlayment panel is the American Plywood Association (APA) underlayment grade plywood, a minimum thickness of 1/4", with a fully sanded face.

Note

Particleboard, chipboard, Masonite, and lauan are not considered to be suitable underlayments.

- C Concrete Floors – Concrete shall have a minimum compressive strength of 3000 psi. New concrete slabs should cure for a minimum of 28 days and meet the relative humidity requirements per ASTM F2710 or the calcium chloride moisture emission test conducted per ASTM F1869 before installing **Recycled Rubber Flooring**. It must be fully cured and permanently dried.

Note

Read further for dryness requirements.

III. SUBFLOOR REQUIREMENTS AND PREPARATION

- A Subfloors shall be dry, clean, smooth, level, and structurally sound. They should be free of dust, solvent, paint, wax, oil, grease, asphalt, sealers, curing and hardening compounds, alkaline salts, old adhesive residue, and other extraneous materials, according to ASTM F710.
- B Subfloors should be smooth to prevent irregularities, roughness, or other defects from telegraphing through the new flooring. The surface should be flat to the equivalent of +/- 3/16" (4.8 mm) in 10' (3.0 m).
- C Mechanically remove all traces of old adhesives, paint, or other debris by scraping, sanding, or scarifying the substrate. Do not use solvents. All high spots shall be ground level and low spots filled with an approved Portland-based patching compound.
- D All saw cuts (control joints), cracks, indentations, and other non-moving joints in the concrete must be filled with an approved Portland-based patching compound.
- E Expansion joints in the concrete are designed to allow for expansion and contraction of the concrete. If a floor covering is installed over an expansion joint, it will likely fail in that area. Use expansion joint covers designed for resilient flooring.

INSTALLATION INSTRUCTIONS FLEX RECYCLED RUBBER FLOORING

Note

Expansion joint covers can be obtained from:

Balco, Inc.

2626 South Sheridan

P.O. Box 17249

Wichita, KS 67217

(800) 767-0082

- F Always allow patching materials to dry thoroughly and install according to the manufacturer's instructions. Excessive moisture in patching material may cause bonding problems or a bubbling reaction with an approved polyurethane adhesive.
- G The maximum moisture vapor emission of the concrete must not exceed 5-1/2 lbs./1,000 sq. ft. in 24-hours, as measured by the calcium chloride moisture emission test conducted per ASTM F1869. Alternatively, if the RH method is used, the maximum RH should not exceed 85% RH tested following ASTM 2710. If the emissions exceed limitations, the installation should not proceed until the problem has been corrected.
- H pH tests must be taken on all concrete floors. If the pH is greater than 9, it must be neutralized before beginning the installation.
- I Adhesive bond tests should be conducted in several locations throughout the area. Glue down 3' x 3' test pieces of the flooring with the recommended adhesive and trowel. Allow it to set for 72 hours before attempting to remove it. A sufficient amount of force should be required to remove the flooring and, when removed, there should be adhesive residue on the subfloor and the back of the test pieces.

Note

This product is suitable for installation over a radiant heat source.

IV. MATERIAL STORAGE AND HANDLING

- A The material should be delivered to the job site in its original, unopened packaging with all labels intact.
- B Roll material should always be stored laying down. Storing rubber on end will curl the edges resulting in the permanent memory of the material. All edges with memory curl must be straight edge cut before installation. Do not store rolls higher than 4 rolls or more than six months. The material should only be stored on a clean, dry, and smooth surface.
- C **Inspect all materials for visual defects before beginning the installation. No labor claim will be honored on material installed with visual defects. Verify the material delivered is the correct style, color, and amount. Any discrepancies must be reported immediately before beginning installation.**
- D The material and adhesive must be acclimated at room temperature for a minimum of 24 hours before starting installation.
- E All **Recycled Rubber Flooring** rolls must be unrolled and installed in the same direction. Laying rolls in the opposite direction will cause color variations between the rolls. Follow the roll sequencing by identifying the log ID and roll number found on the roll label.
- F Roll material is stretched slightly during the manufacturing process. At the job site, the installer should allow all cuts to relax for a minimum of 12 hours (24 hours preferred) before installing. Shaking the material once it is unrolled can help it to relax.

V. INSTALLATION – ROLL MATERIAL

- A Assume that the walls you are butting against are not straight or square. Using a chalk line, make a starting point for an edge of the flooring to follow.
- B Remove the **Recycled Rubber Flooring** from the shrink-wrap and unroll it onto the floor. Lay the **Recycled Rubber Flooring** on the floor in a way that will use your cuts efficiently. Cut all rolls at the required length, including enough to run up the wall.
- C Allow the cuts to relax in position for a minimum of 12 hours. 24 hours is preferred.



STUDIO
COLLECTION

An Intelli-Force Technology Company

INSTALLATION INSTRUCTIONS FLEX RECYCLED RUBBER FLOORING

- D Place the edge of the first roll along the chalk line.
- E Position the second roll with no more than a 1/16" overlap over the first roll at the seam. Work the material back to eliminate the overlap. This procedure will leave tight seams and eliminate any gaps.
- F Repeat for each consecutive roll necessary to complete the area or those rolls that will be installed that day.

Please contact us for specific questions that may not be outlined in these instructions.

G METHOD 1 – GLUE DOWN (Rolls)

Note

3/8" (9mm) or thicker are the only approved thickness for both ice rinks and outdoor applications.

- 1 After performing the above procedures, begin the application of the adhesive. We recommend a one-component moisture-cured polyurethane adhesive. The approved adhesive should not be mixed. It is specially formulated for use right out of the pail. Apply the adhesive to the substrate using a 1/16" x 1/16" x 1/16" square-notched trowel.
- 2 Fold over the first drop along the wall (half the width of the roll).
- 3 Spread the adhesive using the proper size square-notched trowel. Take care not to spread more adhesive than can be covered with flooring within 30 minutes. The open time of the adhesive is 30–40 minutes at 70°F and 50% relative humidity.

Note

Temperature and humidity affect the open time of the adhesive. Temperatures above 70°F and/or relative humidity above 50% will cause the adhesive to set up more quickly. Temperatures below 70°F and/or relative humidity below 50% will cause the adhesive to set up more slowly. The installer should monitor the on-site conditions and adjust the open time accordingly.

- 4 Carefully lay the flooring into the wet adhesive. Do not allow the material to "flop" into place; this may cause air entrapment and bubbles beneath the flooring.

Note

If the adhesive gets onto the finish side of the floor it is important to remove it immediately (while wet) using a microfiber rag and denatured alcohol before it hardens. Apply the denatured alcohol directly to a rag and never directly to the floor. Use denatured alcohol sparingly — saturating the rubber with the denatured alcohol may discolor the floor. Follow the denatured alcohol with a dampened rag with clean water to remove the excess denatured alcohol.

- 5 Immediately roll the floor with a 100 lb. roller to ensure proper adhesive transfer. Overlap each roller pass by 50% of the previous pass to ensure the floor is properly rolled. Roll the width first and then the length. If seams are peaking it may be necessary to weigh them down using concrete construction brinks.
- 6 Fold over the second half of the first roll and half of the second roll. Spread the adhesive. Spread the adhesive at right angles to the seam to prevent the adhesive from oozing up through the seam. Gently lay (do not flop) flooring into the wet adhesive. Roll the flooring.
- 7 Continue the process for each consecutive drop. Work at a pace so that you are always folding material back into wet adhesive.

Note

Never leave adhesive ridges or puddles. They will telegraph through the material.

- 8 Do not allow the adhesive to cure on your hands or the flooring. Immediately wipe off excess adhesive with a rag dampened with denatured alcohol. Cured adhesive is very difficult to remove from hands. We strongly suggest wearing gloves while using an approved polyurethane adhesive.
- 9 **If some seams are gapping, temporarily hold them together with blue painters tape. Do not use duct tape as it may leave a residue on the floor. Important: remove the tape after the adhesive develops a firm set, which is about 2–3 hours. Allowing the blue tape to remain longer than 2–3 hours or using an aggressive tape will cause residue marks.**
- 10 Keep traffic off the floor for a minimum of 24 hours. Foot traffic and rolling loads can cause permanent indentations in the uncured adhesive. If moving equipment onto the floor wait a minimum of 48–72 hours and protect the floor from heavy loads if necessary using 3/4" plywood.



STUDIO
COLLECTION

An Intelli-Force Technology Company

INSTALLATION INSTRUCTIONS FLEX RECYCLED RUBBER FLOORING

H METHOD 2 – TAPE DOWN (9mm Roll)

- 1 Dry lay the rolls onto the subfloor.
- 2 Draw a pencil line beneath all seams to be taped.
- 3 Use a high-quality double-faced carpet tape with a minimum width of two inches. We recommend industrial Double-faced tape 3" x 75' rolls
- 4 Fold over the first drop along the chalk line (half the width of the roll).
- 5 Apply two strips of the double-faced tape along the seam, one on each side of the pencil mark.
- 6 Remove the release paper and place the flooring onto the exposed tape.
- 7 When butting one roll next to another, overlap the seams by no more than 1/16". Work the material back to eliminate the overlap. This procedure will leave tight seams over the tape and eliminate any gaps.
- 8 Hand-roll the seams to ensure adequate contact. Do not roll the entire floor.

Note

The tape method is not an approved procedure for ice rink or outdoor applications. Please contact us for guidelines on ice rinks or outdoor applications.

9 TASKI® CLEANING PROCEDURES

HAZARDS:

SILICA WARNING: Concrete, floor patching compounds, toppings and leveling compounds can contain free crystalline silica. Cutting, sawing, grinding or drilling can produce respirable crystalline silica (particles 1-10 micrometers). Classified by OSHA as an IA carcinogen, respirable silica is known to cause silicosis and other respiratory diseases. Avoid actions that may cause dust to become airborne. Use local or general ventilation or provide protective equipment to reduce exposure to below the applicable exposure limits.

ASBESTOS WARNING: Resilient flooring, backing, lining felt, paint or asphaltic "cutback" adhesives can contain asbestos fibers. Avoid actions that cause dust to become airborne. Do not sand, dry sweep, dry scrape, drill, saw, beadblast or mechanically chip or pulverize. Regulations may require that the material be tested to determine the asbestos content. Consult the document "Recommended Work Practices for Removal of Existing Resilient Floor Coverings" available from the Resilient Floor Covering Institute.

LEAD WARNING: Certain paints can contain lead. Exposure to excessive amounts of lead dust presents a health hazard. Refer to applicable federal, state and local laws and the publication "Lead Based Paint: Guidelines for Hazard Identification and Abatement in Public and Indian Housing" available from the United States Department of Housing and Urban Development.



STUDIO
COLLECTION

An Intelli-Force Technology Company