

CLEANERS / DISINFECTANTS REVIEWED FOR USE ON CRYPTON[®] UPHOLSTERY

Crypton can be cleaned using many different methods and withstand the use of many different cleaners. Below is a list of common cleaners that our researchers have tested on Crypton barrier fabric and the results found following exposure.

CLEANER/DISINFECTANT	ACTIVE INGREDIENT	DISPOSITION [†]
409	Quaternary ammonium	No issues at 10 exposures
3M Neutral Quat	Quaternary ammonium	No issues at 10 exposures
Accel TB	Hydrogen peroxide	No issues at 10 exposures
Acetone	Acetone	UNACCEPTABLE – 5+ exposures in the same area may compromise moisture barrier
Asepticare	Quaternary ammonium	No issues at 10 exposures
Cavicide	Quaternary ammonium, alcohol	No issues at 10 exposures
ChemSpec	Sulfonates	No issues at 10 exposures
Citrus H ₂ O ₂	Hydrogen peroxide	No issues at 10 exposures
Clorox Cleanup (bleach)*	Hypochlorite	Disperse dyed polyester: Exceeding 10% bleach for 10 minutes can result in color loss. UNACCEPTABLE. Cellulosics will have color loss.
Clorox Wipes*	Hypochlorite	No issues at 10 exposures
Crypton Gold	Sulfonates	No issues at 10 exposures
Crypton Purple	Ethoxylate	No issues at 10 exposures
Discide	Quaternary ammonium, alcohol	No issues at 10 exposures
Febreze	Ethanol	No issues at 10 exposures
Greased Lightning*	Alcohols, sulphonic acid	No issues at 10 exposures
Hydrogen Peroxide	Hydrogen peroxide	No issues at 10 exposures
Lysol	Phenols, quaternary ammonium	No issues at 10 exposures
Oasis 146	Quaternary ammonium, alcohols	No issues at 10 exposures
Oxivir TB	Hydrogen peroxide	No issues at 10 exposures
Oxycide	Peroxyacetic acid, hydrogen peroxide	No issues at 10 exposures
PDI Sani Wipe	Quaternary ammonium, alcohol	No issues at 10 exposures
Scotchgard Oxy	Hydrogen peroxide, propanol	No issues at 10 exposures

CONTINUED»

CLEANERS / DISINFECTANTS REVIEWED FOR USE ON CRYPTON® UPHOLSTERY

CLEANER/DISINFECTANT	ACTIVE INGREDIENT	DISPOSITION ¹
Teflon Carpet and Upholstery		No issues at 10 exposures
Viraguard	Isopropanol	No issues at 10 exposures
Virasept	Hydrogen peroxide, acetic acid	No issues at 10 exposures
Virex TB*	Quaternary ammonium	No issues at 10 exposures
Virox 5	Hydrogen peroxide	No issues at 10 exposures
Wexcide 128	Phenols	No issues at 10 exposures
Windex*	Ammonium, alcohols	No issues at 10 exposures

* For Cellulosic and Nylon-containing fabrics, these cleaners have been found to cause color loss or discoloration of the fabric.

¹ Disposition is related to potential loss of Crypton barrier function measured by hydrostatic testing. Color loss attributes are only mentioned for informational purposes.

Only select fiber types have been reviewed for color loss. Results can vary by fiber type and fabric construction. Always check an inconspicuous area first. Thoroughly rinse cleaner/disinfectant for optimal performance and appearance retention.